

AUDIO



SET-UP GUIDE



Table of Contents

Warnings.....	2
Bluetooth Wireless Set-Up (in.stream).....	4
Using in.stream with in.k1000 Topside.....	5
Using in.stream with in.k806 Topside.....	6
Bluetooth Wireless Set-Up:	
Using Bluetooth with Smart Touch WaterProof Display.....	7

NOTE: AUDIO SYSTEM NOT AVAILABLE ON ALL SPAS



WARNINGS:

CAUTION: Audio/Cell Phone/Portable Electronic Devices.

Many consumers own some form of portable electronic device, and some spas come equipped with systems designed to interface with these devices. It is important to protect a spa's audio equipment and your portable electronics by following a few simple procedures:

- Always turn the volume down on your portable electronic device before connecting it to the spa audio system.
- Do not attempt to handle any portable electronic device with wet hands.
- Inspect any area for moisture before setting your portable electronic device in or on it.
- Because of the temperature differential between the warm spa cabinet interior and cooler surroundings outside, moisture is a distinct possibility inside built-in docks. Be sure to wipe these areas out with a dry cloth before connecting any portable electronic device, and do not leave the device inside the dock after exiting the spa.
- Water-resistant covers are available for many popular cell phones and portable music players. These covers are a wise investment for individuals who regularly use their portable electronic devices near hot tubs.
- **CAUTION: Risk of Electric Shock. Do not leave compartment door open.**
- **CAUTION: Risk of Electric Shock. Replace components only with identical components.**
- **WARNING: Prevent Electrocutation. Do not connect any auxiliary components powered by standard household current (for example, cable, additional speakers, headphones, additional audio/video components, etc.) to the system.**
- These units are not provided with an outdoor antennae; if provided, it should be installed in accordance with Article 810 of the National Electrical Code.
- Do not service this product yourself as opening or removing covers may expose you to dangerous voltage or other risk of injury.
Refer all servicing to qualified service personnel.



WARNINGS:

- When the power supply connections or power supply cord(s) are damaged; if water is entering the audio/video compartment or any electrical equipment compartment area; if the protective shields or barriers are showing signs of deterioration; or if there are signs of other potential damage to the unit, turn off the unit and refer servicing to a qualified service personnel.
- This unit should be subjected to periodic routine maintenance (for example, once every 3 months) to make sure that the unit is operating properly.



BLUETOOTH WIRELESS SETUP: in.stream

The audio system is ready to pair with a Bluetooth enabled device when it is not already connected to another device. To pair your device with the system, make sure you are close enough to the equipment side of the spa, and the system is turned on. Below are instructions on how to connect to Bluetooth.

NOTE: The Bluetooth Stereo System is an optional feature available on some models (not limited to the control panels listed in this manual). See your dealer for details if you are unsure what your spa contains.

1. Open the Bluetooth settings on your device. The location of the settings will depend on the device you are using.
2. Turn on Bluetooth on your device.
3. If you see “Gecko in.stream” or “in.stream” from the list of available devices, please reference the below instructions:
 - Choose “**Gecko in.stream**” or “**in.stream**” from the list of available devices
 - When prompted, enter **5555** as the password
 - Your device should now be paired with the in.stream audio system

Note: in.stream operates without a topside on some spa models

The audio system will keep up to 3 devices in its memory. If one of these devices is in range and has its Bluetooth turned on, it will automatically pair with the system. If the number of devices used with your audio system exceeds 3 the first device in its memory will automatically be erased. The device can easily be added again by following the steps above.


If more than one device tries to connect to the audio system, the priority goes to the first device that is available during searching.

Once the pairing is done and connection has been established between the devices, the audio system will be ready to play. If the device moves out of range and loses connection, it should reconnect automatically as soon as it is close enough. This should happen without going through the menu again.



Using in.Stream with in.k1000 Topside

Note: in.stream operates without a topside on some spa models.



This menu is available only if the in.stream was selected in the audio configuration menu.

Turning power On/Off

Go to ON/OFF Sub Menu to turn the in.stream on or off.

Changing tracks

Use the Last Track and Next Track keys to change tracks.

Selecting the source

In the Source Sub menu, only Bluetooth is available.

Disconnect or Unpair Bluetooth

These options can be found under the Bluetooth Sub menu.

Play/Pause audio

Press the Play/Pause button to start or pause the audio.

Speaker

In the Speaker Sub menu; adjust the Balance, Fade and Sub Woofer by sliding the appropriate slider.

Adjusting the volume


Slide the volume icon or touch the mute button to mute or unmute.

Tip: It is possible to erase all pairing information from the memory by holding down the AUX key for 10 seconds.



Using in.Stream with in.k806 Topside

Note: in.stream operates without a topside on some spa models.



Press the **Mode** key to access the audio controls.

Selecting the source – Press the **Bluetooth** key to select a device using Bluetooth wireless technology.

Play/Pause audio – Press the **Play/Pause** key to start or pause the audio.

Adjusting the volume – Press the **Up** and **Down** keys to increase or decrease the volume.

Changing tracks – Use the **Last Track** and **Next Track** keys to change tracks.



BLUETOOTH WIRELESS SET-UP: Using Bluetooth with Smart Touch Waterproof Display

Stereo Sync Operation:

Please select the Main Menu on your Smart Touch Control. Make sure the A/V Option is available.

Please press the **A/V** option on the display.



Powering Up:


Press **POWER** to power on the integrated amplifier/Bluetooth receiver.

The display then shows '*Discoverable*'



Bluetooth Connection:

- 1) On your music device, click search for Bluetooth device. *Make sure you are close enough to the spa.*
- 2) Select "PPGME60" from the pairing list.
- 3) Enter "6000" or "60BT" as the password (if required)
- 4) Click "CONNECT"



Line Input Connection:

This unit can be connected to any portable music devices such as Smart Devices through the MP3 Front enclosure.

Press **SOURCE** to change the mode to **LINE INPUT**

(Line in or Direct light indicator should be on and red)



Note: In this mode, all controls and functions must be controlled from your music device.